



Follow the step by step instructions below on how to make a template of bay window.



Using light weight paper eg Lining paper or wallpaper lay the piece of paper on the floor and overlap the edges onto either the skirting board or the wall and fold the paper up. As illustrated below.

Note : if you don't have one long piece of paper then you can selotape smaller pieces together.





Starting from one corner cut the folded mark using a Stanley knife.
Once you have done this it should look something like this



Once the template has been cut lay the paper against either the skirting board or wall and ensure that you have an accurate cutout.

Write the following details on the template

Your Name

Your Address

Your Contact number

Length and height of radiator

Where the template was taken from : Wall or Skirting board. If it was taken against the skirting board then please write the approx thickness of the skirting board.

You can fold the template up and put into an envelope and post to

**TRADE RADIATORS Ltd,
232 HEADSTONE LANE,
HARROW, HA2 6LY**